


5MP 4in1 Motorized Bullet Camera with Junction Box

● ITEM No: H5B1M



● Caution for Installation

1. In order to prevent electronic shock, don't loosen any screws or covers.
2. Do not directly touch the front glass. If necessary, use a soft cloth moistened with alcohol to wipe off the dust.
3. Avoid places where there are frequent vibrations or shocks.
4. Don't operate the camera beyond its temperature, power source ratings.
5. When any abnormalities happen, make sure to unplug the camera and contact your local dealer.

● Packing


- | | |
|-----------------------------------------|----|
| 1. Camera | X1 |
| 2. User Manual | X1 |
| 3. Screw | X3 |
| 4. Plastic-Conical-Anchor | X3 |
| 5. Hexagonal Wrench | X1 |
| 6. Mounting drawing paper | X1 |
| 7. Junction Box | X1 |
| 8. Power Cable Connector | X1 |
| 9. Video Line | X1 |
| 10. Junction box(including accessories) | X1 |

● Specification

ITEM	H5B1M
IP Rating	IP66
Type	Removable IR Cut Filter
Signal System	NTSC/PAL
Pick Up Device	1/2.8" 5M SONY CMOS
Picture Elements	2688 (H)X1944 (V)
Min Illumination	0Lux(8PCS High Power Led ON)
S/N Ratio	≥50dB
Lens	2.7-13.5mm Motorized Varifocal Fixed Iris Lens
3D	ON
Back Light Compensation	OFF
WDR	ON/OFF
OSD	YES
Video Out-put	5MP TVI/AHD,4MP&2MPTVI/AHD/CVI,CVBS
Power Supply	DC12V ±10%
Current Consumption	680mA(MAX)
Dimension	231×84X110mm (9.1"×3.3" ×4.3")
Weight	28.9oz
Storage Temperature	-22~+149°F
Operating Temperature	-22~+122°F

Remark: Non-regulative adaptor may cause camera damaged.

● video signal output switches



OSD Menu

MAIN MENU

AE	AE	↓	AE	↓
AF	AF	↓	AF	↓
AWB	AWB	↓	AWB	↓
DAY/NIGHT	DAY/NIGHT	↓	DAY/NIGHT	↓
IMAGE ENHANCE	IMAGE ENHANCE	↓	IMAGE ENHANCE	↓
VIDEO SETTING	VIDEO OUTPUT	↓	VIDEO OUTPUT	↓
LANGUAGE	LANGUAGE	← ENGLISH ▶	LANGUAGE	ENGLISH/中文/繁體/русский/Español/ FRANCAIS/POLSKI/ITALIANO/POTUGES/ 한국어
WDR	WDR	← OFF ▶	WDR	OFF/ON
RESET	RESET		RESET	
SAVE&EXIT	SAVE&EXIT		SAVE&EXIT	
EXIT	EXIT		EXIT	

EXPOSURE

BRIGHTNESS	← 36 ▶	BRIGHTNESS	0-100
EXPOSURE MODE	← GLOBAL ▶	EXPOSURE MODE	GLOBE/BLC#
RETURN		RETURN	

AF

AF MODE	← SEMI ▶	AF MODE	SEMI\AUTO\MANUALI
ZOOM	← - / + ▶	ZOOM	-/+
FOCUS	← - / + ▶	FOCUS	-/+
BOOT MODE	← SAVE POS ▶	BOOT MODE	SAVE POS\WIDE END\TELE END
TDN AF	← CLOSE ▶	TDN AF	CLOSE/OPEN
FOCUS TRIGGER	↓	FOCUS TRIGGER	↓
LENS INIT	↓	LENS INIT	↓
RETURN		RETURN	

AWB

MODE	← PRO ▶	MODE	PRO/GRAY WORLD
RETURN	← 44 ▶	RETURN	0-100
BGAIN	← 50 ▶	BGAIN	0-100
RETURN		RETURN	

DAY/NIGHT

MODE	← EXT ▶	MODE	EXT\AUTO\COLOR\MONO
RETURN		RETURN	


IMAGE ENHANCE

CONTRAST	← AUTO ▶	CONTRAST	AUTO\MANUAL#
SHARPNESS	← AUTO ▶	SHARPNESS	AUTO\MANUAL#
SATURATE	← AUTO ▶	SATURATE	AUTO\MANUAL#
3DNR	← AUTO ▶	3DNR	AUTO\MANUAL#
RETURN		RETURN	

VIDEO SETTING

HD	← AHD ▶	HD	AHD
STANDARD	← 5MP20 ▶	STANDARD	1080P25\1080P30\4M 25\4M 30\ 5M 12.5\5M 20
APPLY&REBOOT			
RETURN			
HD	← TVI ▶	HD	TVI
STANDARD	← 4MP30 ▶	STANDARD	1080P25\1080P30\4M 25\4M 30\ 5M 12.5\5M 20
APPLY&REBOOT			
RETURN			
HD	← CVI ▶	HD	CVI
STANDARD	← 4MP30 ▶	STANDARD	1080P25\1080P30\4M 25\4M 30
APPLY&REBOOT			
RETURN			
HD	← CVBS ▶	HD	CVBS
STANDARD	← NTSC ▶	STANDARD	PAL\NTSC
APPLY&REBOOT			
RETURN			

➤ Multi Format HD Analog UTC Control



- (1)- Zoom/focus lens menu
- (2)- Zoom in
- (3)- Enter into camera OSD main menu
- (4)- Zoom out
- (5)- Main menu operation page

1. Zoom/Focus

As picture shown, Click (1) enter into lens menu; Click zoom in; Click zoom out; Click (3) enter into camera OSD main menu.

2. OSD

As picture show, click (5) enter into main menu